



## SPARK W137


INSTRUKCJA MONTAŻU **PL**

Zestaw umożliwia montaż oprawy SPARK SGN LED dłuższym bokiem do ściany z możliwością ustawienia kąta nachylenia 0-90°.

## ELEMENTY ZESTAWU




## WYMIARY (mm)




Należy stosować się do wymagań i zaleceń bezpieczeństwa zawartych w instrukcji montażu oprawy SPARK SGN LED

## INSTALACJA


1. Rozpakować oprawę i zestaw montażowy oraz zweryfikować ich stan po transporcie.
2. Wywiercić otwory w ścianie bądź w suficie pod element mocowany do tej powierzchni zgodnie z rozstawem otworów montażowych (patrz WYMIARY). Przykręcić powyższy element do ściany bądź sufitu. Należy stosować kołki rozporowe oraz wkręty odpowiednie dla podłoża, do którego montowany jest element.



3. Otworzyć oprawę zgodnie z jej instrukcją obsługi.
4. Przełożyć przewody zasilające (oraz komunikacyjne dla wykonania CT) przez przepusty kablowe w elemencie mocowanym do oprawy oraz w podstawie oprawy.
5. Skręcić element mocowany do oprawy z podstawą oprawy. Użyć do tego celu trzech śrub dostarczonych w komplecie zestawu.



6. Skręcić element mocowany do ściany z elementem mocowanym do oprawy. Użyć do tego celu czterech pozostałych śrub, dostarczonych w komplecie zestawu, ustawiając jednocześnie odpowiedni kąt nachylenia.



7. Kolejne czynności wykonywać zgodnie z instrukcją montażu oprawy.


## GWARANCJA

Gwarancja na wyrób obowiązuje pod warunkiem przestrzegania zaleceń i wskazówek producenta oraz użytkowania produktu zgodnie z przeznaczeniem, na okres 12 miesięcy licząc od daty sprzedaży, chyba że wyrób sprzedany został w ramach kontraktu i ten stanowi inaczej. Gwarancja nie obejmuje usterek mechanicznych powstałych z winy klienta, a także usterek wynikłych na skutek złego podłączenia bądź użytkowania wyrobu.

# SPARK W137




## INSTALLATION MANUAL **EN**




The mounting kit is use to mount the SPARK SGN LED luminaires with its longer side to the ceiling or to the wall with the possibility of setting the angle of 0-90°.

### MOUNTING KIT CONTENTS




### DIMENSIONS (mm)




Follow the **SAFETY** included in the SPARK SGN LED luminaire installation manual

## INSTALLATION


1. Unpack the luminaire and mounting kit after transport and verify their condition.
2. Drill holes in the wall or ceiling according to the spacing of the mounting holes (see DIMENSIONS). Screw the wall mounted element to the wall or ceiling. Use dowels and screws, suitable for the base to which the luminaire is mounted.



3. Open the luminaire in accordance with its installation manual.
4. Pass the power cables (and communication cables for the CT version) through the cable gromets in the element mounted to the luminaire and in the luminaire base.
5. Screw the element mounted to the luminaire with the luminaire base. Use the bolts, nuts and washers included in the kit.



6. Screw together the element mounted to the luminaire with element mounted to the wall. Use the four remaining screws, included in the kit, and set the appropriate angle of inclination.



7. Perform the next steps in accordance with the luminaire installation manual.

## WARRANTY

Warranty is valid and enforceable only when manufacturer's recommendations are preserved and the installation and usage are proper. Warranty is granted for a period of 12 months from the date of sale, unless the product has been sold under different contract conditions. The warranty is excluded in case of misuse, unsuitable use, wrong connection or mechanical defects of the product caused by the client.