



SUNON SQR W181



INSTRUKCJA MONTAŻU **PL**

Zestaw umożliwia instalację oprawy SUNON SQR w orientacji bocznej względem ściany z wykorzystaniem kątownika montażowego.

ELEMENTY MOCOWANIA




WYMIARY




Należy stosować się do wymagań i zaleceń bezpieczeństwa zawartych w instrukcji montażu oprawy

INSTALACJA

1. Rozpakować zestaw mocowania i oprawę. Zweryfikować ich stan po transporcie.
2. Wywiercić otwory w ścianie pod kątownik mocowania zgodnie z rozstawem otworów montażowych (patrz WYMIARY).
3. Zamontować kątownik mocowania na ścianie. Należy stosować kołki rozporowe oraz wkręty odpowiednie dla podłoża, do którego montowana jest oprawa. Przełożyć dołączone do zestawu opaski kablowe przez otwory w kątowniku (patrz ELEMENTY MOCOWANIA).
4. Za pomocą dostarczonych wraz z zestawem śrub M4 przykręcić podstawę oprawy do zamontowanego na ścianie kątownika.



5. Przełożyć przewody zasilające (oraz komunikacyjne dla wykonania CT) przez przepusty kablowe w oprawie. Zaciśnąć przygotowane wcześniej opaski kablowe.



6. W razie potrzeby wypoziomować mocowanie regulując docisk wkrętów montażowych.
7. Kolejne czynności wykonywać zgodnie z instrukcją oprawy.


GWARANCJA

Gwarancja na wyrób obowiązuje pod warunkiem przestrzegania zaleceń i wskazówek producenta oraz użytkowania produktu zgodnie z przeznaczeniem, na okres 12 miesięcy licząc od daty sprzedaży, chyba że wyrób sprzedany został w ramach kontraktu i ten stanowi inaczej. Gwarancja nie obejmuje usterek mechanicznych powstałych z winy klienta, a także usterek wynikłych na skutek złego podłączenia bądź użytkowania produktu.

SUNON SQR W181




INSTALLATION MANUAL **EN**





The mounting kit is used to install the SUNON luminaire sideways to the wall with a mounting component.

MOUNTING KIT CONTENTS




DIMENSIONS




Follow the **SAFETY** included in the SUNON luminaire installation manual

INSTALLATION

1. Unpack the luminaire and mounting kit after transport and verify their condition.
2. Drill two holes in the wall according to the spacing of the mounting holes (see DIMENSIONS).
3. Install the mounting component on the wall. Use dowels and screws, suitable for the base to which the luminaire is mounted. Insert the included cable ties through the holes in the mounting component (see MOUNTING KIT CONTENTS).
4. Join the kit together with the luminaire base and screw the M4 screws into the holes of the mounting plate.



5. Pass the power cables (and communication cables for the CT version) through the cable grommets in the mounting plate. Tighten the previously prepared cable ties.



6. If necessary, level the component by adjusting the pressure of the mounting screws.
7. Perform the next steps in accordance with the luminaire installation manual.

WARRANTY

Warranty is valid and enforceable only when manufacturer's recommendations are preserved and the installation and usage are proper. Warranty is granted for a period of 12 months from the date of sale, unless the product has been sold under different contract conditions. The warranty is excluded in case of misuse, unsuitable use, wrong connection or mechanical defects of the product caused by the client.